

## Kitset Planter Boxes 900mm Wide x 400mm High

Planter Size Height = 400mm	Width		Length		Mid Brace		Total Metres	Coach Screws &Washer m10x150	Multigrip	Total	m3 or tonne
Width x Length	Width	No.	Length	No.	Brace	No.					
900x600x400	0.7	4	0.6	4	0.7	0	5.2	16	4	\$360	0.104
900x900x400	0.7	4	0.9	4	0.7	0	6.4	16	4	\$400	0.128
900x1200x400	0.7	4	1.2	4	0.7	0	7.6	16	4	\$439	0.152
900x1500x400	0.7	4	1.5	4	0.7	0	8.8	16	4	\$479	0.176
900x1800x400	0.7	4	1.8	4	0.7	0	10.0	16	4	\$519	0.200
900x2100x400	0.7	4	2.1	4	0.7	0	11.2	16	4	\$559	0.224
900x2400x400	0.7	4	2.4	4	0.7	0	12.4	16	4	\$598	0.248
900x2700x400	0.7	4	2.7	4	0.7	0	13.6	16	4	\$638	0.272
900x3000x400	0.7	4	3	4	0.7	0	14.8	16	4	\$678	0.296
900x3300x400	0.7	4	3.3	4	0.7	0	16.0	16	4	\$718	0.320
900x3600x400	0.7	4	3.6	4	0.7	2	18.6	24	6	\$877	0.372
900x3900x400	0.7	4	3.9	4	0.7	2	19.8	24	6	\$917	0.396
900x4200x400	0.7	4	4.2	4	0.7	2	21.0	24	6	\$957	0.420
900x4500x400	0.7	4	4.5	4	0.7	2	22.2	24	6	\$997	0.444
900x4800x400	0.7	4	4.8	4	0.7	2	23.4	24	6	\$1,036	0.468
900x5100x400	0.7	4	5.1	4	0.7	2	24.6	24	6	\$1,076	0.492

- Timber Size will be 200x100 Macrocarpa Landscape Grade
- Planter will be two boards high = 400mm
- Holes will need to be drilled to allow fixing with coach screws.
- 200x100 will be cut to exact length and square
- Prices include gst