

Kitset Planter Boxes 600mm Wide x 600mm High.

November 2016

Planter Size Height = 600mm Width x Length	Width		Length		Mid Brace		Total Metres	Coach Screws		Total
	No.	No.	No.	No.	No.	No.		&Washer m8x100	Multigrip	
600x600x600	0.5	6	0.6	6	0	0	6.6	24	8	\$211
600x900x600	0.5	6	0.9	6	0	0	8.4	24	8	\$231
600x1200x600	0.5	6	1.2	6	0	0	10.2	24	8	\$251
600x1500x600	0.5	6	1.5	6	0	0	12.0	24	8	\$271
600x1800x600	0.5	6	1.8	6	0	0	13.8	24	8	\$291
600x2100x600	0.5	6	2.1	6	0.5	3	17.1	36	12	\$383
600x2400x600	0.5	6	2.4	6	0.5	3	18.9	36	12	\$403
600x2700x600	0.5	6	2.7	6	0.5	3	20.7	36	12	\$423
600x3000x600	0.5	6	3	6	0.5	3	22.5	36	12	\$443
600x3300x600	0.5	6	3.3	6	0.5	3	24.3	36	12	\$463
600x3600x600	0.5	6	3.6	6	0.5	3	26.1	36	12	\$483
600x3900x600	0.5	6	3.9	6	0.5	6	29.4	48	16	\$576
600x4200x600	0.5	6	4.2	6	0.5	6	31.2	48	16	\$596
600x4500x600	0.5	6	4.5	6	0.5	6	33.0	48	16	\$616
600x4800x600	0.5	6	4.8	6	0.5	6	34.8	48	16	\$636
600x5100x600	0.5	6	5.1	6	0.5	6	36.6	48	16	\$656

- Timber Size will be 200x50 Macrocarpa Landscape Grade
- Planter will be three boards high = 600mm
- Holes will need to be drilled to allow fixing with coach screws.
- 200x50 will be cut to exact length and square
- Price includes gst